Vertical Type Post Indicator / Model A-VPI




Vertical indicator post provides a means to operate a buried or otherwise inaccessible valve and able to indicate the open or shut position of the valve.

For use with 4" to 12" NRS indicating post gate valve

Weight: 90 kg.(198,36lbs.)

Field Adjustment:

1- Remove the Top Section from the top of the Indicator Post assembly;
2- Cut the required stem length
3- Set the "OPEN" and "SHUT" targets for the appropriate valve size;
4- Reattach the Top Section to the top of the Indicator Post assembly.



DIMENSIONS (mm)					
A	B	C	D	E	F
1270	1006	759,5	292	190	305

Wall Type Post Indicator / Model A-WPI




Wall indicator post provides a means to operate a valve installed behind a wall and able to indicate the open or shut position of the valve.
NOTE: Ensure that the non-rising stem gate valve is in the fully open position before installing the Wall Post Indicator.


For use with 4" to 12" NRS indicating post gate valve

Weight: 40,8kg.(90lbs.)

Field Adjustment:

1- Remove the Top Section from the top of the Indicator Post assembly;
2- Cut the required stem length
3- Set the "OPEN" and "SHUT" targets for the appropriate valve size;
4- Reattach the Top Section to the top of the Indicator Post assembly.





Stem

DIMENSIONS (mm)		
A	B	C
497	447	356